

Consumer Products

DIGITAL STILLS CAMERA

SLIDE SWITCH



MMS 224

DOUBLE ACTION
TYPE TACT SWITCH



TSSD 60



TACT SWITCH



TSS 507



TSS 5


DETECTOR SWITCH



DT / DTS



4-DIRECTIONAL SWITCH



TSSJ 5



TSSJ 55

SLIDE SWITCH



MMS 228

BICYCLE LAMPS



SLIDE SWITCH



MFP 130

MP3 PLAYER

RIGHT ANGLE
TACT SWITCH



TSS 5

TACT SWITCH



TSS 17-1



TSS 18



PUSH LEVER
SWITCH



PLSJ 1

SLIDE SWITCH



MMS 228



MMS 224

NOTEBOOK

TACT SWITCH



TSS 507

LED TYPE



TM 2

HALF PITCH
DIP SWITCH



DHS 900



TACT SWITCH



TSS 4-RA



TSS 637-RA

DETECTOR
SWITCH



DT / DTS